

<u>TYPE</u>	<u>HOW TO INSTALL THE BATTERIES IN OUR PROPS</u>	<u>BATTERY</u>
1	WHITE PVC TAPE	PP3
2	IN BASE	PP3
3	THROUGH HOLE IN BASE REQUIRES GAFFA TAPE TO SECURE	PP3
4	THROUGH HOLE IN BASE REQUIRES GAFFA TAPE TO SECURE	PP3
5	THROUGH HOLE IN BASE REQUIRES GAFFA TAPE TO SECURE	PP3
6	THROUGH HOLE IN BASE REQUIRES GAFFA TAPE TO SECURE	PP3
7	IN BASE REQUIRES GAFFA TAPE TO SECURE	PP3
8	IN BASE REQUIRES GAFFA TAPE TO SECURE	PP3
9	THROUGH HOLE IN BASE REQUIRES GAFFA TAPE TO SECURE	PP3
10	THROUGH HOLE IN BASE REQUIRES GAFFA TAPE TO SECURE	PP3
11	THROUGH HOLE IN BASE REQUIRES GAFFA TAPE TO SECURE	PP3
12	IN BASE REQUIRES GAFFA TAPE TO SECURE	PP3
13	IN BASE REQUIRES GAFFA TAPE TO SECURE	PP3
14	IN BASE	PP3
16	IN TOP, WITH VELCRO FIXER	PP3
17	OPEN SIDE, IN BASE	PP3
18	OPEN SIDE, IN BASE	PP3
19	OPEN SIDE, IN BASE	PP3
20	CLIP IN BASE	PP3
21	OPEN SIDE, UNIT IN BASE	PP3
22	UNSCREW HANDLE CAREFULLY, BE CAREFUL NOT TO CROSS THREAD!	PP3
23	OPEN FRONT GLASS	PP3
24	IN BASE REQUIRES GAFFA TAPE TO SECURE	PP3
26	OPEN SIDE, IN BASE	PP3
27	CONNECT BATTERY IN BUM BAG TO THE CHARGER PROVIDED	12 V SEALED
28	CONNECT BATTERY IN BUM BAG TO THE CHARGER PROVIDED	12 V SEALED
31	IN BASE	4.5V NON-RECHARGEABLE
32	OPEN BACK, IN BASE	PP3
33	THROUGH HOLE IN BASE REQUIRES GAFFA TAPE TO SECURE	PP3
34	OPEN SIDE, IN BASE	PP3
35	OPEN SIDE, IN BASE	PP3
36	OPEN BACK, IN BASE	PP3



37 OPEN SIDE, IN BASE	PP3
38 UNSREW TOP CAREFULLY, BE CAREFUL NOT TO CROSS THREAD!	PP3
39 UNSREW TOP CAREFULLY, BE CAREFUL NOT TO CROSS THREAD!	PP3
40 OPEN BACK, IN BASE	PP3
41 IN BASE REQUIRES GAFFA TAPE TO SECURE	PP3
57 OPEN SIDE, IN BASE	PP3
59 TBC	PP3
60 IN BASE	PP3
63 COMPARTMENT IN BASE	PP3
79 FIXED TO BASE	4.5V NON-RECHARGEABLE
81 2 SCREWS TO RELEASE BASE	4.5V NON-RECHARGEABLE
82 OPEN SIDE, IN BASE	PP3
83 OPEN LID	TBC
85 IN BASE	PP3
86 IN BASE	PP3
92 COMPARTMENT IN BASE	PP3
93 UNSREW TOP CAREFULLY, BE CAREFUL NOT TO CROSS THREAD!	PP3
200 IN BASE REQUIRES GAFFA TAPE TO SECURE	PP3
208 REMOVE LID	AA NON RECHARGEABLE
218 UNSREW TOP CAREFULLY, BE CAREFUL NOT TO CROSS THREAD!	PP3
226 OPEN TOP	TBC
227 OPEN FRONT, IN BASE	PP3
327 OPEN FLASH GUN TUBE	3 X D NON-RECHARGEABLE
348 TBC	PP3
349 TBC	PP3
352 TBC	PP3
356 IN BASE	PP3
380 IN FOAM INSIDE BOX	PP3
396 OPEN FRONT, IN BASE	PP3
446 UNSREW TOP CAREFULLY, BE CAREFUL NOT TO CROSS THREAD!	PP3

